


DRILLING JIG SK.1





MORSE TAPER ADAPTER



WHERE A ROTARY TABLE HAS A MORSE TAPER BORE AN ADAPTER WILL BE REQUIRED. THE THREAD ENABLES THE ADAPTER TO BE JACKED OUT WITHOUT REMOVING THE ROTARY TABLE FROM THE MACHINE TABLE.

THE SPACER IS ONLY REQUIRED FOR SOME OPERATIONS

LOCATER AND ACCESSORIES SK. 2



LOCATER



SPACER